

Technical Specifications

- Height: 23"; Width: 14.5" x 14.5"
- Weight 35 lbs.
- Perforated steel intake housing (filter deck); 360° intake
- Air flow output from upper deck, directed one side
- Bottom plate easily removed for filter access
- Baked-on powder coat finish
- Available in silver only

Allergy Machine™



Specifically designed for people with asthma and allergies

Developed by the British military for use against chemical warfare, Austin is the only air cleaner manufacturer to use HEGA (High Efficiency Gas Absorption) in their air cleaners. The Austin Air Allergy Machine™ cleans up to 1500 square feet, with strategically placed military carbon cloth and True Medical HEPA filter media.

Filter Assembly

- 13.5" diameter, 14.5" height
- 60 sq. ft. true HEPA medical filter medium
- Special layer of military carbon cloth
- Meets HEPA standards, trapping 99.97% of all particulates larger than 0.3 microns
- Foam sealing gaskets top and bottom
- Total weight 13 lbs

PERMAFILT Prefilter

- Traps large dust particles
- Designed to be vacuumed from outside and eliminate costly 3 month filter changes

Fan and Motor Assembly

- Centrifugal fan
- 3 Speed control switch
- Power rating: 1.3 amps, 120 volts
- 115 Watt power consumption at highest setting
- Motor type: permanent split capacitor, rated for continuous high RPM, long life duty
- Motor mounted on shock absorbers
- CSA and UL approved

Fan Rating:

- 400cfm on high setting; cleans a room area of up to 1500 sq. ft.

Warranty:

- 5 years on all parts and labor

Filter Guarantee:

- 5 year pro-rated guarantee under normal residential use

Austin

A I R S Y S T E M S

Your Qualified Austin Air Dealer:

Distributed by:

Filtera.com

toll-free:

888-933-0100