

## Technical Specifications

- Height: 23"; Width: 14.5" x 14.5"
- Weight 45 lbs.
- Perforated steel intake housing (filter deck); 360° intake
- Air flow output from upper deck, directed one side
- Bottom plate easily removed for filter access
- Baked-on powder coat finish
- Available in sandstone, white and black

# HealthMate



## Featuring America's Number 1 Filter

Austin Air cleaners have been consistently rated at the top of air cleaner categories in independent testing. The HealthMate™ cleans up to 1500 square feet, with 15 lbs. of Carbon-Zeolite mix and True Medical HEPA filter media for adsorption of odors and gases.

## Filter Assembly

- 13.5" diameter, 14.5" height
- 60 sq. ft. true HEPA medical filter medium
- Nearly 15 lbs mixture of solid activated carbon and zeolite
- Meets HEPA standards, trapping 99.97% of all particulates larger than 0.3 microns
- Foam sealing gaskets top and bottom
- Total weight 23 lbs

## PERMAFILT Prefilter

- Traps large dust particles
- Designed to be vacuumed from outside and eliminate costly 3 month filter changes

## Fan and Motor Assembly

- Centrifugal fan
- 3 Speed control switch
- Power rating: 1.3 amps, 120 volts
- 115 Watt power consumption at highest setting
- Motor type: permanent split capacitor, rated for continuous high RPM, long life duty
- Motor mounted on shock absorbers
- CSA and UL approved

## Fan Rating:

- 400cfm on high setting; cleans a room area of up to 1500 sq. ft.

## Warranty:

- 5 years on all parts and labor

## Filter Guarantee:

- 5 year pro-rated guarantee under normal residential use

# Austin

A I R S Y S T E M S

Your Qualified Austin Air Dealer:

Distributed by:

**Filtera.com**

toll-free:

**888-933-0100**