

Allergy Machine Jr.™

Technical Specifications

- Height: 16.5"; Width: 11" x 11"
- Weight 12 lbs.
- Perforated steel intake housing (filter deck); 360° intake
- Air flow output from upper deck, directed one side
- Bottom plate easily removed for filter access
- Baked-on powder coat finish
- Available in sandstone, white and black



Designed For Allergy & Asthma Sufferers

Designed specifically for allergy and asthma sufferers. It provides identical particle removal capacity and efficiency of the HealthMate Jr.™. Because the carbon cloth does not release carbon dust when air passes through it, the design of the filter places the True Medical HEPA paper on the outside of the filter allowing the air to pass through the paper before it passes through the carbon. Because of this design, all of the airborne particles are removed before the air contacts the carbon. The total surface area of the carbon is available for gas removal only and its useful life is increased.

Filter Assembly

- 9.75" diameter, 11.25" height
- 30 sq. ft. true HEPA medical filter medium
- Activated carbon in woven cloth form
- Meets HEPA standards, trapping 99.97% of all particulates larger than 0.3 microns
- Foam sealing gaskets top and bottom
- Total weight 2.5 lbs

PERMAFILT Prefilter

- Traps large dust particles
- Designed to be vacuumed from outside and eliminate costly 3 month filter changes

Fan and Motor Assembly

- Centrifugal fan
- 3 Speed control switch
- Power rating: 1 amp, 120 volts
- 80 Watt power consumption at highest setting
- Motor type: high efficiency shaded pole motor rated for continuous high RPM, long life duty
- Motor mounted on shock absorbers
- CSA and UL approved

Fan Rating:

- 200cfm on high setting; cleans a room area of up to 700 sq. ft.

Warranty:

- 5 years on all parts and labor

Filter Guarantee:

- 5 year pro-rated guarantee under normal residential use

Austin

A I R S Y S T E M S

Your Qualified Austin Air Dealer:

Distributed by:

Filtera.com

toll-free:

888-933-0100