

Technical Specifications

- Height: 16.5"; Width: 11" x 11"
- Weight 18 lbs.
- Perforated steel intake housing (filter deck); 360° intake
- Air flow output from upper deck, directed one side
- Bottom plate easily removed for filter access
- Baked-on powder coat finish
- Available in sandstone, white and black

HealthMate+ Jr.™



Relief for Chemical Sensitivities

The HealthMate+ Jr.™, provides the same benefits as the standard HealthMate Jr.™, the impregnation of potassium iodide (along with the zeolite), provides greater relief for people with severe chemical sensitivities.

Effective for an area of up to 700 sq/ft, assuming average residential ceiling heights of 8 ft. Provides effective coverage for single rooms including bedrooms and individual offices.

Filter Assembly

- 9.5" diameter, 11.25" height
- 30 sq. ft. true HEPA medical filter medium
- 6.5 lbs activated carbon impregnated with potassium iodide and zeolite (ten to one to one ratio)
- Meets HEPA standards, trapping 99.97% of all particulates larger than 0.3 microns
- Foam sealing gaskets top and bottom
- Total weight 8 lbs

PERMAFILT Prefilter

- Traps large dust particles
- Designed to be vacuumed from outside and eliminate costly 3 month filter changes

Fan and Motor Assembly

- Centrifugal fan
- 3 Speed control switch
- Power rating: 1 amp, 120 volts
- 80 Watt power consumption at highest setting
- Motor type: high efficiency shaded pole motor rated for continuous high RPM, long life duty
- Motor mounted on shock absorbers
- CSA and UL approved

Fan Rating:

- 200cfm on high setting; cleans a room area of up to 700 sq. ft.

Warranty:

- 5 years on all parts and labor

Filter Guarantee:

- 5 year pro-rated guarantee under normal residential use

Austin

A I R S Y S T E M S

Your Qualified Austin Air Dealer:

Distributed by:

Filtera.com

toll-free:

888-933-0100