



Filtera
 12999 Murphy Road, Suite I-1
 Stafford, Texas 77477-3948
 281.933.1100 Phone
 888.933.0100 Toll Free Phone
 281.933.1159 Fax
 www.Filtera.com
 info@Filtera.com



SPACE BARON Ducted Filter Replacements Available in MERV 8 and MERV 11

APPLICATIONS

Space Baron filters are designed as third-party replacement filters for use in the ducted filter systems listed.

STANDARD FEATURES & OPTIONS:

Uses Intrepid* Filtration Media

Space Baron filters utilize Intrepid filtration media from Kimberly Clark. This gradient density media is electrostatically charged and is 100% synthetic. The media is thermally bonded with no chemical binders. This media is resistant to a wide range of chemicals, does not absorb moisture and will not support microbial growth.

Superior frame strength

Space Baron frames utilize double wall construction and the die-cut fingers separating the media add extra strength and frame rigidity.

Designed to limit air bypass

The filter media is laminated to an expanded metal backing. The media is continuously bonded to the inside of the filter frame. Exterior gaskets are standard on selected models as required.

Fully assembled

These filters come fully assembled and are ready to install in the original manufacturer's filter housing.

Choose from two efficiency levels

Better: MERV 8
Best: MERV 11

UL CLASSIFICATION

Space Baron filters are rated by Underwriters Laboratories as UL CLASS 2 and have a maximum temperature rating of 180 degrees Fahrenheit.

*Intrepid is a registered trademark of Kimberly-Clark Worldwide, Inc. ©2003 KCWW

Replacements For:

Brand / Model*	Nominal Size
Trion "Air Bear Cub"	16 x 25 x 3
Trion "Air Bear"	20 x 25 x 5
Research Products "Space Gard 2200"	20 x 24 x 6
Honeywell "FC100A1029"	16 x 25 x 5
Honeywell "FC100A1037"	20 x 25 x 5
White Rogers "F825-0548"	16 x 26 x 5
White Rogers "F825-0549"	20 x 26 x 5
General Filter "AC-1"	20 x 24 x 5

* Trademarks and company names are used for identification purposes only.

Please check with us if your brand or model is not shown. Additional sizes are available.

Prices and specifications are subject to change without notice. All sales are made subject to the terms and conditions contained in the Filtera, Statement of Business Policy, as revised from time to time, a current copy of which is available upon request.